Please read carefully and use according to the instructions!



## Instructions for tying the safety rope to the spring for the BABY hammock

Fold the safety rope in half.



Seller: Hojdavak s.r.o., Company ID 21203423, Prague 10 - Benice, Okrasná 114, ZIP code: 103 00 tel. +420720752328, info@hojdavak.cz, www.hojdavak.cz

1



HOJDAVAK Safety rope for BABY

SPRING

We thread the ends of the rope through its eye, creating a fox loop.

Thread both ends of the rope through the spring and tighten slightly.

slightly.

Seller: Hojdavak s.r.o., Company ID 21203423, Prague 10 - Benice, Okrasná 114, ZIP code: 103 00 tel. +420720752328, info@hojdavak.cz, www.hojdavak.cz



Place a carabiner with a safety catch in the lower eye of the spring.

Pass one end of the rope through the eye of the spring and the carabiner at the same time. Safety rope for BABY SPRING

HOJDAVAK

We create a knot on the rope at a distance of approximately 60 cm from the upper carabiner.

If the knot prevents swinging, we can loosen it and move it a longer distance as needed.

## WE NEVER REMOVE THE ROPE COMPLETELY!

Seller: Hojdavak s.r.o., Company ID 21203423, Prague 10 - Benice, Okrasná 114, ZIP code: 103 00 tel. +420720752328, info@hojdavak.cz, www.hojdavak.cz



HOJDAVAK

Safety rope for BABY SPRING

To keep the rope out of the way, we can tie another knot around the spring eye.

Now the spring is ready to use for the BABY hammock.

## TAKE THE TEST!

Before first use, and after each manipulation with the safety rope, test the correct installation of the cradle.

Grasp the large carabiner under the spring and, by applying downward pressure, stretch the spring as far as the safety rope will allow.



At maximum spring tension, the cradle should hang above the ground. If the cradle touches the ground, shorten the safety rope by moving both knots up closer to the spring.